KODAK PIXPRO 4KVR360

360° VR CAMERA



BLUETOOTH Remote Control

Remote Control - C



Remote Control - D



Record Button - Start/Stop Video, Capture Photo & Pair BLUETOOTH/Power Button

BLUETOOTH/Power Button - For pairing via BLUETOOTH or powering camera on/off

Camera Mode - Video or Photo

Capture Mode - 360° Spherical Photo VR Mode (Lens A & Lens B),


197° 4K Ultra Wide Mode & 235° Dome Mode

BLUETOOTH Remote Control Instructions

Pairing the Cameras and Remote Controls:

1. This method is for one remote control to one camera:

With the camera turned on, press the (11) button
for 2 seconds to enter the pairing mode.



Press and hold the and buttons on the remote control simultaneuosly until pairing is successful.

While pairing, the remote control should be close to the camera.



2. Press the button on the remote control to start shooting or recording and press the button again to stop recording.

Other camera settings and parameters remain the same as preselected movie or still camera settings.

3. To turn the camera off, press the (11) button.

© 2017 JK Imaging Ltd. The Kodak trademark, logo and trade dress are used under license from Eastman Kodak Company. All other logos, products or company names that are referred to on this document are trade names, trademarks or registered trademarks of their holders. The holders are not affiliated with JK Imaging Ltd., our products or our website. Document Number/Sequence: U.DIS.0047.0417.en.01